
EC591 Lab 4 Report Notes

4.1 Al A representative plot of measured signal versus lateral position (after background subtraction) is shown in the figure below. The circles show the measured data and the solid line is a fit to a Gaussian curve. From the fit you can determine W(z1) (the half width at 1/e, maximum of the peak).



The larger pinhole (100-um diameter) allows for more light to be transmitted and therefore results in a larger signal-to-noise ratio for the measured data. The pinhole diameter limits the measurement spatial resolution. Therefore, the smaller pinhole (25-um diameter) allows for higher resolution. However, since the full width of all measured peaks is larger than a few 100 um, using the larger pinhole is appropriate for these measurements.

4.1 B) W(zz) is the half width at 1/ez maximum of the intensity Profile measured at Zz = Z1 + 400 mm

$$\Rightarrow \begin{cases} W(z_1) = \sqrt{\frac{1}{T}} \sqrt{1 + \left(\frac{2}{Z_0}\right)^2} \\ W(z_2) = \sqrt{\frac{1}{T}} \sqrt{1 + \left(\frac{2}{Z_0}\right)^2} \end{cases} \text{ two unknowns } (z_1 \text{ and } z_0)$$

with 2=632.8 nm, d=400 mm

After solving this system of equations for Zo and ZI, you can colculate $Z_2 = Z_1 + d$, $W_o = \sqrt{\frac{1}{T}}, \theta_o = \frac{W_o}{Z_o}$

The solutions for Wo and Oo should be close to the specified values of 0.4 mm and 0.0005 rad, respectively (although the exact values are different for different lasers in the lab).

The Rayleigh range to should be on the order of several 100 mm.

The solution for Z1 should be such that the Waist of the Gaussian beam is somewhere near the center of the laser cavity.

The beam radius at the focal point Wo can be computed from:

 $W(z_2) = W_0 \sqrt{1 + Z_2^2 \left(\frac{2}{TW_0^2}\right)^{27}}$ the solution for W_0 should be smaller than in 4.1C

half width at 1/ez maximum of intensity profile measured at Zz

and be assumed to occur at the beam wast

The angle of the shear plate a is related to the fringe spacing of as follows: $d = \frac{\lambda}{2n\lambda}$, where $n \approx 1.5$ is the refractive index of the plate.

Typical wedge angles for the shear plates in the lab are on the. order of a few 10 arcsec (~ 10-4 rad), producing fringe spacings of a few mm